

Installation Guide for FLOOR DRAINS



Floor Drain capacity 35 Litres per Minute.
Available in 300mm, 600mm & 900mm

Installation:

- Ensure that there is enough space for the floor drain and siphon, so that it can be properly connected. Make sure that no drain pipe is strained or otherwise they are more prone to leak.
- Remove the gutter grate to prevent damage to the visual element, and prevent any debris to enter the floor drain.
- Connect the floor drain using the collar provided to the 50mm drain pipe. Set the adjustable legs to make sure the floor drain is level all round. This step is very important as otherwise the water trap will not function correctly thus allowing foul odours to escape the drain system and into the bathroom.
- Make sure that the height of the floor drain is correct and in line with the finished floor level. Ensure that the tiles are 1mm higher than the gutter edge.
- Use the membrane matt provided and ensure that it is well glued to the floor drain and the rest of the shower membrane.
- Once tiled, silicone the edge of the floor drain to the tiles.

