INSTALLATION INSTRUCTIONS

Cons. 6V Sensor 184mm Mixer Tap

Bridgepoint SKU: ID700.A9/1 Idral code: 700.A9/1

1. GENERAL INFORMATION

- Installation must be carried out by professionally qualified personnel and the plumbing system must comply with current regulations.
- Flush supply pipework before installation. Use filtered water and provide accessible isolation valves for maintenance.

2. INSTALLATION

- Prepare the wall/concealed mounting position to the dimensions on the original Idral Technical Specification.
- Secure the body/box and connect water supplies with the required filters and isolation valves.
- Complete the finished wall around the manufacturer cover plate without obstructing inspection access.
- Connect the battery power source only after hydraulic installation has been checked.

3. COMMISSIONING

- Open the isolation valves and check all connections for leaks.
- Ensure the sensor window is clean and unobstructed, then connect power. Wait for the sensor start-up sequence to complete.
- Check sensor operation and confirm automatic shut-off. Detection distance can be adjusted where required according to the manufacturer instructions.