INSTALLATION INSTRUCTIONS

EASY Ergonomic Ceramic Basin with Overflow

B&M SKU: **ID10191** Idral code: **10191**

Before installation

Inspect the product and all supplied components. Confirm the model, dimensions, installation position and compatibility of taps, waste and plumbing. Protect finished surfaces and isolate the water supply where applicable.

Installation sequence

1. Confirm the finished mounting height and mark the fixing points from the official drawing and the actual basin.

2. Verify that the wall is sound and select fixings suitable for the wall construction and imposed load. Fixings are not included.

3. Drill carefully, install structural fixings and hang/support the basin level without point loading the ceramic.

4. Fit the separately supplied tap, waste and siphon/trap. Do not overtighten fittings against the ceramic.

5. Seal the basin-to-wall junction with suitable sanitary-grade sealant where required.

6. Open the supply, test the waste and overflow, and confirm that the basin is stable and all connections are leak-free.

Important

Installation must be carried out by a competent installer. Site conditions determine the required structural fixings. Stop work if the product is damaged, dimensions do not match, or the supporting construction is unsuitable.

Retain the official technical specification and proof of purchase. Damage caused by unsuitable cleaners, impact, incorrect installation or incompatible components is not a manufacturing defect.